



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	431	"O" ring	822	Rear drag plate
14	Handle shaft coat	452	Reel foot screws	823	Embedded clip
17	Washer 2	503	Fixed screws	824	Close cover
39	Button screw	500	Reel foot	825	Cover
66	Spool spring washer	546	Drive shaft washer	826	Drag plate
69	Spool washer	574	Button basement	827	Spool shaft
178	Set plate nail	581	T handle nail	831	Drive shaft coat
185	"E" washer	584	Push nail	832	Drive shield
195	Rod clamp	593	Push slice	833	Spring cover for silence
202	Handle knob screw 1	594	Stopping slice	859	Button lever knob
207	Push slice screw	598	Handle bolt washer	860	Drag tension knob
211	Set plate screws	601	Washer 3	863	High speed pinion gear
214	Alert ratchet screws	602	Handle knob screw 2	864	Low speed pinion gear
215	Cover screw	603	Push spring	865	Drive gear-high speed
379	Ball bearing (S117)	604	Spool shaft spring	866	Drive gear-low speed
381	Ball bearing (S606)	629	Handle knob	867	Drive shaft
384	Ball bearing (S6700)	630	"O" ring	868	Push button shaft
390	Ball bearing (S696)	631	Wrench	869	Slide pole
398	Pre-program plate	656	Spool spring washer	871	Variable-speed pin
406	Set plate	657	Alarm sound gear	872	Handle bolt
416	"E" washer	665	Big ring	873	Strike alert lever
417	Drag knob cover	666	Small ring	878	Anti-reverse ratchet
418	Sound coat	668	Side plate screws	884	"C" washer
419	Pre-program key pin	670	Close cover screws	885	Handle washer
420	Sound nail	679	Washer 1	887	Drive shaft spring
421	Bearing cover	681	Alert ratchet	888	Shaft insert spring
423	Drag plate washer	697	Handle arm	889	Drive shaft coat washer
424	Spool shaft screw	698	Spool ring	891	Variable-speed washer
425	Screw embedded clip	816	Right plate	897	Drag plate undersleeve
426	Screw for bearing cover	817	Frame	899	Friction ring
428	Sound nail spring	818	Spool	901	Pre-program key
429	Bearing ring	819	Drag control lever	910	Anti-reverse dog
430	Drag control lever washer	820	Spool cannulation		