



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	503	Fixed screws	860	Drag tension knob
14	Handle shaft coat	506	Reel foot	862	Spool shaft
17	Washer 2	546	Drive shaft washer	863	High speed pinion gear
39	Button screw	574	Button basemant	864	Low speed pinion gear
66	Spool spring washer	581	T handle nail	865	Drive gear-high speed
69	Spool washer	584	Push nail	866	Drive gear-low speed
178	Set plate nail	593	Push slice	867	Drive shaft
185	"E" washer	594	Stopping slice	868	Push button shaft
195	Rod clamp	598	Handle bolt washer	869	Slide pole
202	Handle knob screw 1	601	Washer 3	870	Spool cannulation
207	Push slice screw	602	Handle knob screw 2	871	Variable-speed pin
211	Set plate screws	603	Push spring	872	Handle bolt
214	Alert ratchet screws	604	Spool shaft spring	873	Strike alert lever
215	Cover screw	629	Handle knob	878	Anti-reverse ratchet
379	Ball bearing (S117)	630	"O" ring	884	"C" washer
381	Ball bearing (S606)	631	Wrench	885	Handle washer
384	Ball bearing (S6700)	657	Alarm sound gear	886	Reel foot screws
390	Ball bearing (S696)	665	Big ring	887	Drive shaft spring
406	Set plate	666	Small ring	888	Shaft insert spring
416	"E" washer	668	Side plate screws	889	Drive shaft coat washer
417	Drag knob cover	670	Close cover screws	890	Cover
418	Sound coat	679	Washer 1	891	Variable-speed washer
419	Pre-program key pin	681	Alert ratchet	892	Drag plate
420	Sound nail	697	Handle arm	895	Drag control lever
421	Bearing cover	703	Spool ring	896	Spool
423	Drag plate washer	829	Right plate	897	Drag plate undersleeve
424	Spool shaft screw	830	Frame	898	Spool spring washer
425	Screw embedded clip	831	Drive shaft coat	899	Friction ring
426	Screw for bearing cover	832	Drive shield	900	Pre-program plate
428	Sound nail spring	833	Spring cover for silence	901	Pre-program key
429	Bearing ring	834	Embedded clip	909	Close cover
430	Drag control lever washer	835	Rear drag plate	910	Anti-reverse dog
431	"O" ring	859	Button lever knob		